



# Maxos, Accessoires

## 9MX056 CBA BK

### Chain bracket adjustable

The swivel device is a versatile mechanical connecting device for Maxos TL-D and TL5 light-lines and enables variable angles between the light-lines. The minimum angle is 45 degrees. Due to its attractive design it is often used in application areas such as shops, schools and museums. Up to four light-lines can be connected with one swivel device. The housing is made of plastic, with a white or silver coating, and with inner supporting elements made of steel. If needed, the swivel device can accommodate lighting control sensors, loudspeakers, etc. It is pre-mounted with an adjustable quick hanger with a 1.25 m steel suspension wire. One dedicated coupling piece (9MX056 CP-SD WH/SI) per trunking section is necessary to connect the trunking to the swivel device. Electrical components for mains feed-through have to be ordered as required.

### Données du produit

Caractéristiques générales		Circuit	
Classe de protection CEI	-		Non [-]
Accessoires pour suspension	CBA [ Chain bracket adjustable]	Matériaux et finitions	
Accessoires mécaniques	Non [-]	Longueur	- mm
Configuration d'emballage	No [-]	Dimensions (hauteur x largeur x profondeur)	NaN x NaN x NaN mm (NaN x NaN x NaN in)
Couleur des accessoires	Noir	Normes et recommandations	
Accessoires d'éclairage de secours	Non [-]	Code d'indice de protection	-
Code de la famille de produits	9MX056 [ ACC MAXOS]	Données logistiques	
Photométries et colorimétries		Code de produit complet	403073225202200
Cache optique/type d'accessoire pour objectif	Non [-]	Nom du produit de la commande	9MX056 CBA BK
Caractéristiques électriques		Code barre produit	4030732252022
Accessoires électriques	Non [-]		

## Maxos, Accessoires

Code de commande	25202200
Numérateur - Quantité par kit	1
Conditionnement par carton	1
SAP - Matériaux	910629113626

Poids net (pièce)	0,115 kg
-------------------	----------

